

What to do if...


What to do if...

A tire punctures	P. 516	If you have a flat tire
The hybrid system does not start	P. 108	Immobilizer system
	P. 530	If the hybrid system will not start
	P. 535	If the 12 volt battery is discharged
The high coolant temperature warning light comes on	P. 540	If your vehicle overheats
Steam can be seen coming from under the hood		
The key is lost	P. 532	If you lose your keys
The 12 volt battery runs out	P. 535	If the 12 volt battery is discharged
The doors cannot be locked	P. 67	Side doors
	P. 72	Back door
The vehicle is stuck in mud or sand	P. 545	If the vehicle becomes stuck

The warning light or indicator  
light comes on

P. 488

If a warning light turns on or a  
warning buzzer sounds...



n **Warning lights**



Master warning light  
P. 489



Charging system  
warning light P. 489



Malfunction indicator  
lamp

or



P. 489



Brake system warning  
light (red indicator)

or



P. 488

Brake system warning  
light (yellow indicator)



P. 489

Automatic headlight  
leveling system  
warning light P. 489



Open door warning light  
P. 491



SRS warning light  
P. 489



ABS warning light

or



P. 489



Tire pressure warning  
light P. 491



Electric power steering  
warning light P. 489



Pre-collision system  
warning light P. 489



High coolant temperature  
warning light P. 491



Low fuel level warning  
light P. 491



Driver's seat belt reminder  
light P. 491



Front passenger's seat  
belt reminder light P. 491





